



**Espace**

Type

Sub-section

JE0 X

38

**38 BOSCH 5.3 ABS WITH SPEED INFORMATION FUNCTION**

- Engine: XXX
  - Gearbox: XXX
- Basic manual: N.T. 3034A

This note is in addition to Technical Note 3034A.

**Contents**

		Page
<b>38</b>	<b>ELECTRONICALLY CONTROLLED HYDRAULIC SYSTEMS</b>	
	<b>BOSCH ABS</b>	
	Operating principle	38-1
	Wiring diagram	38-2
	Wiring diagram key	38-3
	31 track connector	38-4
	Tyre circumference	38-5
	Interchangeability of computer and complete hydraulic assembly	38-5
	<b>Fault finding</b>	
	Introduction	38-6
	XR25 fiche	38-7
	Interpretation of XR25 bargraphs	38-9
	Checking conformity	38-10
	Aid	38-11
	Customer complaint	38-12
	Fault chart	38-13

"The repair methods given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The methods may be modified as a result of changes introduced by the manufacturer in the production of the various component units and accessories from which his vehicles are constructed."

All copyrights reserved by Renault.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of Renault.

The new BOSCH 5.3 ABS computers fitted to the ESPACE provide a vehicle speed signal (this signal replaces that from the speed sensor located on the gearbox).

### **OPERATING PRINCIPLE**


The ABS computer calculates the vehicle speed from the wheel speed and the tyre circumference in the memory (see page 38-9).



### WIRING DIAGRAM KEY

- 104** Ignition switch
- 120** Injection computer
- 150** Rear right hand wheel sensor
- 151** Rear left hand wheel sensor
- 152** Front right hand wheel sensor
- 153** Front left hand wheel sensor
- 160** Stop switch
- 225** Diagnostic socket
- 247** Instrument panel
- 373** Cruise control unit
- 597** Engine fuse box
- 645** Passenger compartment connection unit
- 721** ABS hydraulic assembly and computer
- 866** Diesel injection computer
- 1016** Passenger compartment electronic unit
- R183** Intermediate connection - engine connection unit / **ABS**
- R262** Connection - passenger compartment- engine compartment

## 31 TRACK COMPUTER



DIM3801

**A** Micro-spring connecting to earth (terminal 19) and pin 21 (ABS and NIVOCODE warning lights) in case connector is disconnected.

## Allocation of connector tracks

Track	Description	Track	Description
1	RRH sensor earth	15	+ after ignition computer feed
2	Not connected	16	Pump motor earth
3	RRH sensor information	17	+ BATT (solenoid valves and pump motor)
4	FRH sensor earth	18	+ BATT (solenoid valves and pump motor)
5	FRH sensor information	19	Electronic earth
6	FLH sensor earth	20	Not connected
7	FLH sensor information	21	ABS fault warning light
8	RLH sensor earth	22	Vehicle speed information
9	RLH sensor information	25	Not connected
10	Not connected	26	Not connected
11	Diagnostic line K	27	Not connected
12	Diagnostic line L	31	Not connected
13	Not connected		
14	Stop lights switch information		

## Bosch ABS

The tyre circumference is to be programmed into the memory of the new computer. This is done by entering the wheel diameter configuration (**G30\*X\***) using the fault finding tool.

TYRES	VALUE TO ENTER ("X")
195/65/15	45
205/65/15	96
215/65/15	147
215/55/16	76
225/55/16	121

Following entering of the value, erase the computer memory then switch off the ignition.

The tachometer value (**#30**) can be used to check the correct value has been entered.

#### INTERCHANGEABILITY OF COMPUTER AND COMPLETE HYDRAULIC ASSEMBLY

Since the computers and hydraulic assemblies of the BOSCH 5.3 ABS are mechanically, hydraulically and electrically completely interchangeable, with or without the speed information function, the part numbers have been unified.

For exchange or repair only computers with the speed information function are fitted, even on vehicles fitted with the first generation computer as standard (without the speed information function).

When a computer is replaced, when the ignition is switched on, the ABS warning light will flash rapidly to indicate that the tyre circumference has not been programmed. This is used to calculate the vehicle speed (even if the computer speed information function is not used on the vehicle).

The ABS warning light can be made to stop flashing using the **configuration of wheel diameter (G30\*X\*)**.

ABS computers with the speed information function are identified by the following **computer number (#12)**

:

### FAULT FINDING - INTRODUCTION

#### CONDITIONS FOR APPLYING THE CHECKS DEFINED IN THIS FAULT FINDING DOCUMENT

The checks defined in this fault finding document are only to be applied to the vehicle where the title of the fault dealt with corresponds exactly to the display noted on the fault finding tool.

If a fault is dealt with when the bargraph is flashing, the conditions for confirming the actual presence of the fault (and the necessity of applying the fault finding) are given in the "Notes" section or at the start of the interpretation of the bargraph.

If a bargraph is only interpreted in the case where it is permanently illuminated, applying the checks recommended in the fault finding when the bargraph is flashing will not allow the origin of the memorisation of the fault to be determined. In this case, only a check of the wiring and connections of the component at fault may be carried out (the fault is simply memorised as it is not present at the time of checking).

**NOTE :** the ignition must be switched off before the fault finding tool is used.

#### TOOLING REQUIRED FOR OPERATIONS ON THE ABS SYSTEM

Fault finding tools.

#### **Reminders:**

When an intermittent fault is memorised, the ABS warning light will illuminate when the vehicle is next used until a speed equal to 7.5 mph (12 km/h) is reached. When the fault is memorised, a counter associated with the fault is set to 40. This counter is decreased each time the ignition is switched on if the fault is not present when the vehicle speed exceeds 7.5mph (12 km/h).

When the counter reaches 1, it is no longer decreased and the fault is not erased.

FAULT FINDING - XR25 FICHE

N°53		S8	code : <b>D 1 1</b>	read : <b>n.53</b>
1	<input type="checkbox"/>	FEED / COMPUTER	CODE PRESENT	<input type="checkbox"/>
2	<input type="checkbox"/>	FR LH	INLET SOL. VALVE CIRCUIT	FR RH <input type="checkbox"/>
3	<input type="checkbox"/>	RR LH		RR RH <input type="checkbox"/>
4	<input type="checkbox"/>	FR LH	EXHAUST SOL. VALVE CIRCUIT	FR RH <input type="checkbox"/>
5	<input type="checkbox"/>	RR LH		RR RH <input type="checkbox"/>
6	<input type="checkbox"/>	FR LH	WHEEL SPEED SENSOR CIRCUIT	FR RH <input type="checkbox"/>
7	<input type="checkbox"/>	RR LH		RR RH <input type="checkbox"/>
8	<input type="checkbox"/>	FR LH	WHEEL SPEED SIGNAL SENSORS	FR RH <input type="checkbox"/>
9	<input type="checkbox"/>	RR LH		RR RH <input type="checkbox"/>
10				PUMP MOTOR CIRCUITS #30 <input type="checkbox"/>

### BOSCH ABS

Erase fault memory : G 0 \*\*  
End of test : Q13 \*

11	<input type="checkbox"/>	SOL. VALVE FEED	
12	<input type="checkbox"/>	STOP CIRCUIT (CO)	TARGET FOR ONE WHEEL <input type="checkbox"/>
13	<input type="checkbox"/>	BRAKE PEDAL DEPRESSED $\longleftrightarrow$ RELEASED <input type="checkbox"/>	
14	<input type="checkbox"/>	SPEEDO FUNCTION NOT PROGRAMMED (see Manual)	
15			
16			
17			
18			
19			
20			

#### ADDITIONAL CHECKS : # . .

(see note)

01	FR RH wheel speed	Km/h
02	FR LH wheel speed	Km/h
03	RR RH wheel speed	Km/h
04	RR LH wheel speed	Km/h
06	feed	volts
14	Speed	Km/h

#### 12 computer identification

256.5	IF ESPACE
228.5	IF KANGOO/CLIO
221.5	
214.5	IF SAFRANE P12
213.5	IF SAFRANE (P12 speeds)
238.5	
231.5	IF MEGANE

#### CONTROL MODES : G...\*

(If veh. speed is zero and for  
BV tests, depress brake  
pedal)

03	Test FR LH sol. valves
04	Test FR RH sol. valves
05	Test RR LH sol. valves
06	Test RR RH sol. valves
20	Engine and sol. valve static test

NOTE : for safety, the computer can exit diag. when driving along

**18** ANG

FI21853

### FAULT FINDING - XR25 FICHE

#### BARGRAPH SYMBOLS

##### FAULTS (always on a coloured background)




If illuminated, this indicates a fault on the product tested. The associated text defines the fault.

The bargraph may be :

- Permanently illuminated : fault present.
- Flashing : fault memorised.
- Extinguished : no fault or fault not found.

##### STATUS (always on a white background)



Bargraph always at the top right hand side.


If illuminated dialogue has been established with the computer for the product.

If it remains extinguished:

- The code does not exist.
- There is a fault with the tool, the computer or the XR25 / computer connection.

The representation of the following bargraphs indicates their initial status:

Initial status: (ignition on, engine stopped, no operator action)



or

Indefinite

illuminated when the function or condition on the fiche is met.



Extinguished



Illuminated

extinguishes when the function or condition specified on the fiche is no longer being met.

#### ADDITIONAL NOTES

Certain bargraphs have a \*. The \*.. command, when the bargraph is illuminated, allows additional information on the type of fault or status to be displayed.

## Bosch ABS

14



Bargraph 14 LH side

Speed information programming**NOTES**

None.

The **BOSCH 5.3** ABS computer with "speed information" function is capable of providing a vehicle speed signal to all the users of this information in the vehicle (engine management, passenger compartment connection unit,...).

This vehicle speed signal will replace that currently supplied by the speed sensor on the gearbox.

The ABS computer calculates the vehicle speed from the wheel speeds and the circumference of the tyres fitted to the vehicle.

**The tyre circumference is to be programmed into the memory of the new computer. This is done by entering the wheel diameter configuration (G30\*X\*) using the fault finding tool.**

TYRES	VALUE TO ENTER ("X")
195/65/15	45
205/65/15	96
215/65/15	147
215/55/16	76
225/55/16	121

Following entering of the value, erase the computer memory then switch off the ignition.  
The tachometer value (#30) can be used to check the correct value has been entered.

**AFTER REPAIR**

Erase the computer memory (G0\*\*).  
Carry out another check using the fault finding tool.

## Bosch ABS

## FAULT FINDING - CHECKING CONFORMITY

<b>NOTES</b>	None
--------------	------

Order	Function	Title	Display and notes	Diagnostic
1	Battery voltage	<b>Parameter (#06)</b> : Computer feed voltage	11.6 <X< 13.2 V	<b>If there is a fault, refer to the fault finding for this parameter</b>
2	Computer conformity	<b>Parameter (#12)</b> : Computer number	233.5	<b>None</b>
3	Reading the value	<b>Parameter (#30)</b> : Speed information value	45 47 96 76 121	<b>45 = 195/65/15</b> <b>47 = 215/65/15</b> <b>96 = 205/65/15</b> <b>76 = 215/55/16</b> <b>121 = 225/55/16</b>

## Bosch ABS

Using the commands:Operating the solenoid valves for a hydraulic test:

Lift the vehicle to check that the wheels turn freely.  
Hold the brake pedal down to prevent the wheel to be tested from turning if it is turned by hand (do not brake too hard so that you are at the releasing limit).

Use the **wheel solenoid valve command (G0X\*)** → The wheel concerned should lock / release ten times.

Operating the pump motor:

Use the **pump motor test command (G08\*)** → and press the brake pedal The motor should operate for **2 seconds**.

Operating the pump motor and the solenoid valves:

Execute the **static actuator test (G020\*)** → and press the brake pedal The motor and the solenoid valves should operate briefly.

Bleeding the hydraulic circuits:

Follow the procedure described in the section "**Bleeding the circuits**" in **N.T. 3034A**.

Replacing the computer:

The **BOSCH 5.3** ABS computer with "speed information" function is capable of providing a vehicle speed signal to all the users of this information in the vehicle (engine management, passenger compartment connection unit, ...).

This vehicle speed signal will replace that currently supplied by the speed sensor on the gearbox.

The ABS computer calculates the vehicle speed from the wheel speeds and the circumference of the tyres fitted to the vehicle.

**The tyre circumference is to be programmed into the memory of the new computer. This is done by entering the wheel diameter configuration (G30\*X\*) using the fault finding tool.**

TYRES	VALUE TO ENTER ("X")
195/65/15	45
205/65/15	96
215/65/15	147
215/55/16	76
225/55/16	121

Following entering of the value, erase the computer memory then switch off the ignition.  
The tachometer value (**#30**) can be used to check the correct value has been entered.

### FAULT FINDING - CUSTOMER COMPLAINT

<b>NOTES</b>	Only refer to this customer complaint after a complete check using the fault finding tool.
--------------	--

<b>FAULTS NOTED IN OPERATION OF THE WARNING LIGHT</b>
---

— No vehicle speed information on the instrument panel.

**Chart 1**

## FAULT FINDING - FAULT CHART

<b>Chart 1</b>	<b>NO VEHICLE SPEED INFORMATION ON THE INSTRUMENT PANEL (COMPUTER WITH SPEED INFORMATION FUNCTION)</b>
----------------	--

<b>NOTES</b>	Only refer to this customer complaint after a complete check using the fault finding tool.
--------------	--

Check using the fault finding tool for the presence or absence of vehicle speed information on the other systems which use the signal from the ABS computer (engine management, passenger compartment connection unit,...).

- If the instrument panel is the only system not receiving the signal, ensure the continuity of the connection between track **22** on the ABS computer and track **17** on the **blue 26 track connector (F)** for the passenger compartment connection unit.
- If no system is receiving the signal, look for a continuity or insulation fault on the connection between track **22** on the ABS computer connector and the various users of the vehicle speed information or an internal fault in one of the signal user systems (proceed by making successive disconnections).

If the fault persists after these checks, replace the ABS computer.

<b>AFTER REPAIR</b>	Carry out a road test then a check with the fault finding tool.
---------------------	---